

DRAPER[®]

230V MOBILE

AIR CONDITIONING UNIT

56124 - AC9000B

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY TO ENSURE THE SAFE AND EFFECTIVE USE OF THIS PRODUCT.



INSTRUCTIONS

These instructions accompanying the product are the original instructions. This document is part of the product, keep it for the life of the product passing it on to any subsequent holder of the product. Read all these instructions before assembling, operating or maintaining this product.

This manual has been compiled by Draper Tools describing the purpose for which the product has been designed, and contains all the necessary information to ensure its correct and safe use. By following all the general safety instructions contained in this manual, it will ensure both product and operator safety, together with longer life of the product itself.

All photographs and drawings in this manual are supplied by Draper Tools to help illustrate the operation of the product.

Whilst every effort has been made to ensure the accuracy of information contained in this manual, the Draper Tools policy of continuous improvement determines the right to make modifications without prior warning.

1. TITLE PAGE

1.1 INTRODUCTION:

USER MANUAL FOR:

230V MOBILE AIR CONDITIONING UNIT

Stock no. 56124.

Part no. AC9000B.

1.2 REVISIONS:

Date first published November 2016

As our user manuals are continually updated, users should make sure that they use the very latest version.

Downloads are available from: <http://www.drapertools.com/manuals>

DRAPER TOOLS LIMITED

HURSLEY ROAD

CHANDLER'S FORD

EASTLEIGH

HAMPSHIRE

SO53 1YF

UK

WEBSITE: drapertools.com

PRODUCT HELPLINE: +44 (0) 23 8049 4344

GENERAL FAX: +44 (0) 23 8026 0784

1.3 UNDERSTANDING THIS MANUALS SAFETY CONTENT:

WARNING! Information that draws attention to the risk of injury or death.

CAUTION! Information that draws attention to the risk of damage to the product or surroundings.

1.4 COPYRIGHT © NOTICE:

Copyright © Draper Tools Limited.

Permission is granted to reproduce this publication for personal & educational use only.

Commercial copying, redistribution, hiring or lending is prohibited.

No part of this publication may be stored in a retrieval system or transmitted in any other form or means without written permission from Draper Tools Limited.

In all cases this copyright notice must remain intact.

2. CONTENTS

2.1 CONTENTS

	Page
Page content	
1 TITLE PAGE	
1.1 INTRODUCTION	2
1.2 REVISION HISTORY	2
1.3 UNDERSTANDING THIS MANUAL	2
1.4 COPYRIGHT NOTICE	2
2 CONTENTS	
2.1 CONTENTS	3
3 GUARANTEE	
3.1 GUARANTEE.....	4
4 INTRODUCTION	
4.1 SCOPE.....	5
4.2 SPECIFICATION.....	5
4.3 HANDLING & STORAGE.....	5
5 HEALTH & SAFETY INFORMATION	
5.1 GENERAL SAFETY INSTRUCTIONS.....	6
5.2 CAUTION: RISK OF ELECTRIC SHOCK. DO NOT OPEN.....	7
6 TECHNICAL DESCRIPTION	
6.1 IDENTIFICATION.....	8-9
7 UNPACKING & CHECKING	
7.1 PACKAGING.....	10
7.2 WHAT'S IN THE BOX?.....	10
8 INSTALLATION INSTRUCTIONS	
8.1 INSTALLATION INSTRUCTIONS.....	11
8.2 DUCT MOUNT INSTRUCTIONS.....	11
8.3 WINDOW KIT INSTALLATION	12
9 OPERATING INSTRUCTIONS	
9.1 COOLING OPERATION	13
9.2 DEHUMIDIFYING OPERATION	13
9.3 TIMER OPERATION.....	14
9.4 WATER PUMP DRAINAGE	15
9.5 CONTINUOUS DRAINAGE	15
10 MAINTENANCE	
10.1 AIR FILTER.....	16
10.2 CLEAN THE AIR CONDITIONER SURFACE.....	16
11 TROUBLESHOOTING	
11.1 TROUBLESHOOTING	17
10 EXPLANATION OF SYMBOLS	
10.1 EXPLANATION OF SYMBOLS.....	18
11 DISPOSAL	
11.1 DISPOSAL	19
DECLARATION OF CONFORMITY	ENCLOSED

3. GUARANTEE

3.1 GUARANTEE

Draper products have been carefully tested and inspected before shipment and are guaranteed to be free from defective materials and workmanship.

Should the tool develop a fault, please return the complete unit to your nearest distributor or contact Draper Tools Limited, Chandler's Ford, Eastleigh, Hampshire, SO53 1YF. England.

Telephone Sales Desk: (023) 8049 4333 or Product Helpline (023) 8049 4344.

A proof of purchase must be provided with the unit.

If upon inspection it is found that the fault occurring is due to defective materials or workmanship, repairs will be carried out free of charge. This guarantee period covering parts/labour is 12 months from the date of purchase except where tools are hired out when the guarantee period is 90 days from the date of purchase. The guarantee is extended to 24 months for parts only. This guarantee does not apply to normal wear and tear, nor does it cover any damage caused by misuse, careless or unsafe handling, alterations, accidents, or repairs attempted or made by any personnel other than the authorised Draper warranty repair agent.

Note: If the unit is found not to be within the terms of warranty, repairs and carriage charges will be quoted and made accordingly.

This guarantee applies in lieu of any other guarantee expressed or implied and variations of its terms are not authorised.

Your Draper guarantee is not effective unless you can produce upon request a dated receipt or invoice to verify your proof of purchase within the guarantee period.

Please note that this guarantee is an additional benefit and does not affect your statutory rights. Draper Tools Limited.

4. INTRODUCTION

4.1 SCOPE

A Portable Air Conditioner works by removing the heat from the surrounding environment, it then expels this heat out via an exhaust hose, typically this is placed out of an open window, reducing the temperature of the room.

4.2 SPECIFICATION

Stock no.	56124
Part no.	AC9000B
Rated voltage	220-240V~50Hz
Rated input	980W
Cooling capacity	9000btu/h
Air flow volume	320M ³ /h
Refrigerant.....	R410A
.....	GWP=2088 with CO ² equivalent of 0.60552 tonnes.
Moisture removal.....	0.9L/h
Noise level.....	<65dB(A)
Dimensions (WxHxD)	330x280x680mm
Weight (machine only)	19kg

4.3 HANDLING & STORAGE

Care must still be taken when handling and lifting. Dropping this machine will have an effect on the performance and may also result in personal injury. This machine is not a toy and must be respected.

The environment will have a negative result on its operation if you are not careful. If the air is damp, components will rust. If the machine is unprotected from dust and debris; components will become clogged: And if not cleaned and maintained correctly or regularly the machine will not perform at its best.

5. HEALTH & SAFETY INFORMATION

5.1 GENERAL SAFETY INSTRUCTIONS

WARNING: Read all instructions. Failure to follow all instructions listed below may result in electric shock, fire and/or serious injury.

Save all warnings and instructions for future reference.

1. Do not connect the unit to any AC power supply in disrepair, or with loose connections.
2. Do not use in the following locations:
 - Next to source of fire.
 - An area where oil is likely to splash, or spill.
 - An area exposed to direct sunlight.
 - An area where water is likely to splash or spill.
3. Never insert your fingers or any foreign objects into the air outlet. Take special care to warn children of these dangers.
4. Always store the unit upright in order to maintain the compressor in its proper condition.
5. Be sure to unplug the unit before cleaning.
6. When moving the air-conditioner, always turn off and disconnect the power supply, and move it slowly.
7. To avoid the possibility of fire, the air-conditioner must not be covered.
8. The air-conditioner plug must comply with the local electric safety requirements. If necessary, please check before use.
9. Young children should be supervised to ensure that they do not play with the appliance.
10. This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capacities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Notes:

- If any parts are damaged, please contact the dealer or a designated repair shop;
- In case of any damage, please turn off, disconnect the power supply, and contact the dealer or a designated repair shop;
- To avoid the possibility of danger, if power cord is damaged, please turn off and disconnect the power supply. It must be replaced by dealer or a designated repair shop.

WARNING

In use condensation may form on the base of the unit. **DO NOT** use on sensitive or absorbent surfaces (carpet, unprotected wood floors etc). Base must be on a flat, level surface to operate correctly and efficiently.

5. HEALTH & SAFETY INFORMATION

5.2 CAUTION: RISK OF ELECTRIC SHOCK. DO NOT OPEN.

Caution: Risk of electric shock. Do not open.

This appliance is supplied with a moulded 3 pin mains plug for your safety. The value of the fuse fitted is marked on the pin face of the plug. Should the fuse need replacing, ensure the substitute is of the correct rating, approved to BS1362 and ASTA or BS Kite marked.

ASTA 


BSI 

The fuse cover is removable with a small plain slot screwdriver. Ensure the fuse cover is replaced before attempting to connect the plug to an electrical outlet. If the cover is missing, a replacement must be obtained or the plug replaced with a suitable type.

If a replacement plug is to be fitted this must be carried out by a qualified electrician.

The damaged or incomplete plug, when cut from the cable should be disabled to prevent connection to a live electrical outlet.

This appliance is Class I[†] and is designed for connection to an earthed power supply matching that detailed on the rating label and compatible with the plug fitted.

Earthed : This product requires an earth connection to protect against electric shock from accessible conductive parts in the event of a failure of the basic insulation.

Important: On products exceeding 2000W it is recommended that the power cable is fully extended before a connection is made to the power supply. We do not recommend the use of extension cables with this unit.

6. TECHNICAL DESCRIPTION

6.1 IDENTIFICATION





- ① Control panel
- ② Cool air outlet
- ③ Castors
- ④ Dust screen

- ⑤ Hot air outlet
- ⑥ Grill cover
- ⑦ Drain plug
- ⑧ Mains power supply plug and cable

6. TECHNICAL DESCRIPTION

6.1 IDENTIFICATION



- ⑨ Remote control
- ⑩ Fan speed selector
- ⑪ Temp+ Temperature selector up
- ⑫ Mode select
- ⑬ Temp- Temperature selector down

- ⑭ Timer
- ⑮ Power On/Off switch
- ⑯ Remote signal sensor
- ⑰ Digital display

7. UNPACKING & CHECKING

7.1 PACKAGING

Carefully remove the product from the packaging and examine it for any sign of damage that may have happened during shipping. Lay the contents out and check them against the parts shown below. If any part is damaged or missing; please contact the Draper Helpline (the telephone number appears on the Title page) and do not attempt to use the tool.


The packaging material should be retained at least during the guarantee period: in case the machine needs to be returned for repair.

Warning! Some of the packaging materials used may be harmful to children. Do not leave any of these materials in the reach of children.

If any of the packaging is to be thrown away, make sure they are disposed of correctly; according to local regulations.

7.2 WHAT'S IN THE BOX?

As well as the product; there are several parts not fitted or attached to it.



- (15) Flexible exhaust hose square connector
- (16) Exhaust flat connector
- (17) Exhaust hose

8. INSTALLATION INSTRUCTIONS

8.1 INSTALLATION EXPLANATIONS




IMPORTANT:

Install the mobile air conditioner unit on a flat surface where the air outlets will not be covered up. A minimum clearance of 30cm from a wall or other obstacles is required.

8.2 DUCT MOUNT INSTRUCTIONS - FIGS. 1 - 4

Screw either end of the flexible exhaust hose (17) into the square connector (15) and the flat connector (16).

Slot the square connector (15) onto the back of the mobile air conditioner. Place the other end out of the window.



8. INSTALLATION INSTRUCTIONS



8.3 WINDOW KIT INSTALLATION - FIGS. 5 - 6

The window kit has been designed to fit most standard Vertical and Horizontal window applications.

However, it may be necessary to improvise or modify some aspects of the installation procedures for certain types of window.

Slider Kit (Stock No.60555)

Length from min.67.5cm - max.123cm.



9. OPERATING INSTRUCTIONS


CAUTIONS FOR COOLING AND DEHUMIDIFYING OPERATIONS:

WARNING: In use condensation may form on the base of the unit, DO NOT use on sensitive or absorbent surfaces. Base must be on a flat, level surface to operate correctly and efficiently.

- When using functions on cooling and dehumidifying, keep an interval of at least 3 minutes between each ON/OFF.
- Ensure that the power supply meets the unit requirements.
- The socket is for AC use.
- IMPORTANT: Do not use other items in the same socket outlet as the mobile air conditioning unit.
- Power supply is AC 220-240V, 50Hz


9.1 COOLING OPERATION - FIG. 7

1. Press the "Mode" button till the "Cool" illuminates.
2. Press the "▲" or "▼" button to select a desired room temperature. (16°C-31°C)
3. Press the "Fan Speed" button to select wind speed High or Low.



9.2 DEHUMIDIFYING OPERATION - FIG. 8

1. Press the "Mode" button till the "Dehumidify Indicator Lamp" illuminates.
2. When in dehumidifier operation, the display will show the current room temperature minus 2°C. This is normal.
3. Fan motor is automatic only LOW wind speed.




9. OPERATING INSTRUCTIONS

9.3 TIMER OPERATION - FIGS. 9 - 10


TIMER ON SETTING:

1. When the air-conditioner is OFF, press the "Timer" button and select a desired ON time through the temperature and time setting buttons.
2. "Preset ON Time" is displayed on the operation panel.
3. ON time can be regulated at any time in 0-24 hours.



TIMER OFF SETTING

4. When the air-conditioner ON, press "Timer" button and select a desired OFF time through the temperature and time setting buttons.
5. "Preset OFF Time" is displayed on the operation panel.
6. OFF time can be regulated at any time in 0-24 hours.




9. OPERATING INSTRUCTIONS

9.4 WATER DRAINAGE - FIGS. 11-12

During use the unit will extract water from the air moving through it. This collects in the integral tank and would normally evaporate during and after use.

However, if the air is excessively humid the water tank will fill up and an automatic float switch will turn the unit off. And the "W.F." light will flash on the control panel (fig12). If this happens, switch off the unit, place a suitable water container under the unit and remove the rubber drain plug (fig 11). Once empty, replace the rubber drain plug and restart the machine if required.



9.5 CONTINUOUS DRAINAGE

When you plan to leave this unit unused for a long time (after draining the tank as above), please remove the rubber drain plug from the drainage hole at the bottom of unit.


10. MAINTENANCE

METHOD

- 1) Before cleaning, be sure to disconnect the unit from any electric supply outlet;
- 2) Do not use gasoline or other chemicals to clean the unit;
- 3) Do not wash the unit directly;
- 4) If the conditioner is damaged, please contact the dealer or repair shop.

10.1 AIR FILTER - FIGS. 13 - 14

- In use air filters will become clogged with dust/dirt. The air filters should be cleaned once every two weeks.
- Pull the handle to slide the top air filter out (fig.13). Push down lightly on the clips to remove the bottom filter (fig, 14).
Clean the air filter with neutral detergent in lukewarm (40°C) water and leave to dry.
- Mounting
Replace the components once dry.



10.2. CLEAN THE AIR-CONDITIONER SURFACE

First clean the surface with a mild neutral detergent and damp cloth, and then wipe it with a dry cloth. DO NOT WASH WITH RUNNING WATER.

11. TROUBLESHOOTING

11.1 TROUBLESHOOTING

TROUBLES	POSSIBLE CAUSES	SUGGESTED REMEDIES
Unit does not start when pressing power button	Water full indicator lamp blinks, and water tank is full.	Empty the water out of the water tank.
	Room temperature is lower than the setting temperature. (Cooling mode)	Reset the temperature
Not cool enough	The doors or windows are not closed.	Make sure all the windows and doors are closed.
	There are heat sources inside the room.	Remove the heat sources if possible.
	Exhaust air hose is not connected or blocked.	Connect or clean the exhaust air hose.
	Temperature setting is too high.	Reset the temperature
	Air inlet is blocked.	Clean the air inlet.
Noisy	The ground is not level or not flat enough.	Place the unit on a flat, level ground if possible.
	Sound comes from flowing refrigerant inside the air conditioner.	This is normal.
E0 Code	Room temperature sensor failed.	Return to service agent to replace room temperature sensor.
E2 Code	Water tank full.	Please empty the water tank.

12. EXPLANATION OF SYMBOLS

12.1 EXPLANATION OF SYMBOLS



WEEE
Do not dispose of Waste Electrical
& Electronic Equipment in with
domestic rubbish



Class I construction
earthed.



Single value noise marking
(Maximum declared
A-Weighted sound power
level in decibels).



Warning!
Read instruction manuals before
operating and servicing this
equipment.



Unplug immediately if the power
cord or plug becomes damaged.



For indoor use only.
Do not expose to rain.

13. DISPOSAL

13.1 DISPOSAL

- At the end of the machine's working life, or when it can no longer be repaired, ensure that it is disposed of according to national regulations.
- Contact your local authority for details of collection schemes in your area.

In all circumstances:

- Do not dispose of power tools with domestic waste.
- Do not incinerate.
- Do not abandon in the environment.
- Do not dispose of WEEE* as unsorted municipal waste.



* Waste Electrical & Electronic Equipment.

CONTACTS

- **DRAPER TOOLS LIMITED,**
Hursley Road, Chandler's Ford,
Eastleigh, Hampshire. SO53 1YF. U.K.
- **Helpline:** (023) 8049 4344
- **Sales Desk:** (023) 8049 4333
- **General Enquiries:** (023) 8026 6355
- **Service/Warranty Repair Agent**
For aftersales servicing or warranty repairs, please
contact the Draper Tools Helpline for details of an
agent in your local area.

YOUR DRAPER STOCKIST

RDMC1116

