



SUBMERSIBLE WATER PUMP AUTOMATIC LOW LEVEL 2MM 117LTR/MIN 230V

MODEL NO: **WPL117A**

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to instructions


1. ELECTRICAL SAFETY

- ❑ **WARNING!** It is the owner's responsibility to read, understand and comply with the following:
You must check all electrical equipment and appliances to ensure they are safe before using. You must inspect power supply leads, plugs and all electrical connections for wear and damage. You must ensure the risk of electric shock is minimised by the installation of appropriate safety devices. An RCCB (Residual Current Circuit Breaker) should be incorporated in the main distribution board. We also recommend that an RCD (Residual Current Device) is used with all electrical products. It is particularly important to use an RCD together with portable products that are plugged into an electrical supply not protected by an RCCB. If in doubt consult a qualified electrician. You may obtain a Residual Current Device by contacting your Sealey dealer. You must also read and understand the following instructions concerning electrical safety.

The Electricity At Work Act 1989 requires all portable electrical appliances, if used on business premises, to be tested by a qualified electrician, using a Portable Appliance Tester (PAT), at least once a year.

The Health & Safety at Work Act 1974 makes owners of electrical appliances responsible for the safe condition of the appliance and the safety of the appliance operator. If in any doubt about electrical safety, contact a qualified electrician.

- ✓ Ensure the insulation on all cables and the product itself is safe before connecting to the mains power supply. The pump and cable are designed for submerging in water and as such must not be tampered with (if in doubt, contact a qualified electrician).
- ✓ Ensure that cables are always protected against short circuit and overload.
- ✓ Regularly inspect power supply leads, plugs and all electrical connections for wear and damage, especially power connections, to ensure that none is loose.
Ensure the voltage marked on the product is the same as the electrical power supply to be used, and check that plugs are fitted with the correct capacity fuse. A 13 amp plug may require a fuse smaller than 13 amps for certain products, see fuse rating at right.
- ✗ **DO NOT** pull or carry the appliance by its power supply lead.
- ✗ **DO NOT** pull power plugs from sockets by the power cable.
- ✗ **DO NOT** use worn or damaged leads, plugs or connections. Immediately replace or have repaired by a qualified electrician. A U.K. 3 pin plug with ASTA/BS approval is fitted. In case of damage, cut off and fit a new plug according to the following instructions (discard old plug safely).
(UK only - see diagram at right). Ensure the unit is correctly earthed via a three-pin plug.
 - a) Connect the GREEN/YELLOW earth wire to the earth terminal 'E'.
 - b) Connect the BROWN live wire to live terminal 'L'.
 - c) Connect the BLUE neutral wire to the neutral terminal 'N'.
 - d) After wiring, check that there are no bare wires, that all wires have been correctly connected, that the cable outer insulation extends beyond the cable restraint and that the restraint is tight.
- ✓ Only allow the minimal amount of pump cable to enter water or wet areas. The electrical cable is designed for use in water and must not be substituted. If damaged contact a qualified electrician.
- ✓ Extension cable use. Only use a cable designed for use with water equipment. Contact your dealer or a qualified electrician advice
- ✓ Ensure water is kept clear of electrical mains power supply. **DO NOT** touch switch or plug with wet hands.



1.1. GENERAL SAFETY

- ❑ **WARNING!** Pump must be used in accordance with Health & Safety, government, local authority, and water authority rules and regulations.
- ✓ Familiarise yourself with application and limitations, as well as the specific potential hazards peculiar to the pump.
- ❑ **WARNING!** Disconnect the pump from the mains power before changing accessories, servicing or performing any maintenance.
- ✓ Maintain the pump in good condition (use an authorised service agent). Keep the pump clean.
- ✓ Replace or repair damaged parts. Use genuine parts only. Unauthorised parts may be dangerous and will invalidate the warranty.
- ✓ Only use for pumping clean cold or warm water (**NOT** exceeding 35°C).
- ✓ If the bottom of the area to be cleared is covered with sludge, sand, gravel or mud etc, suspend the pump or place it on a raised base to operate above the solid matter. Sand and such substances will reduce working life of pump, and invalidate your warranty..
- ✗ **DO NOT** operate the pump if any parts are damaged or missing as this may cause failure and/or possible personal injury.
- ✗ **DO NOT** use the pump for any purpose other than that for which it is designed.
- ✗ **DO NOT** use to pump chemicals, fuels or salt water.
- ✗ **DO NOT** insert hands into the mouth of the pump as this could lead to injury.
- ✗ **DO NOT** use to pump septic tanks or settling pits. **DO NOT** pump any liquids other than water.

- ✗ **DO NOT** operate the pump out of water. The pump pick up area must be completely submerged during operation.
 - ✗ **DO NOT** exceed the maximum submersible depth (see specifications: Max. Water Depth).
 - ✗ **DO NOT** operate the pump during freezing temperatures. **DO NOT** leave the pump in water that may freeze.
 - ✗ **DO NOT** use for pumping sea water or inflammable, corrosive, explosive or dangerous liquids.
 - ✗ **DO NOT** carry the pump by its electrical cable, or its outlet pipe. Use the handle only.
 - ✗ **DO NOT** leave the pump unattended if the float switch is manually fixed in the 'on' position.
 - ✓ When not in use, switch off pump and remove plug from power supply. Rinse pump, drain out any water and store in a frost free, safe location.
 - ☐ **WARNING! DO NOT** allow uncontrolled discharge of contaminated water which would pollute the environment.
- N.B:- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Clean and user maintenance shall not be made by children without supervision.

2. INTRODUCTION


Manufactured from corrosion resistant materials with stainless steel motor case and Noryl® base cover. Fitted with automatic cutout. Puddle pump with minimum water depth of just 2mm makes this ideal for flood recovery. Designed for clean water although these pumps will accept small particles up to 5mm. Suitable for the effective drainage of cellars, sinks, cisterns, baths and the general transfer of water.

3. SPECIFICATION

Model No.....WPL117A
 Cut Out..... Automatic
 Outlet OD 32mm
 Maximum Output.....117ltr(26gal)/min
 Maximum Head..... 8mtr
 Maximum Water Depth..... 7mtr
 Minimum Water Depth 2mm
 Maximum Partical Size..... 5mm
 Motor Power.....400W
 Supply230V

4. OPERATION

- ☐ **WARNING!** Ensure you read, understand and apply safety instructions.
- 4.1. Fit an appropriate discharge pipe to pump outlet and secure with a clip. Ensure the diameter of the discharge pipe is the same as or greater than the outlet diameter, as a smaller pipe will adversely effect the pump flow rate.
- 4.2. Position the pump in the water accordingly, and place the outlet pipe securely in the discharge receptacle or area. It is recommended that the pump is sunk with its discharge outlet facing up, to release any trapped air.
- 4.3. Connect the pump to the electrical mains supply and switch it on.
- 4.4. **USING AS A CONVENTIONAL SUBMERSIBLE PUMP:** The pump will turn on automatically as the level of water rises (fig.1.A). As the water level lowers, the float will switch the pump off automatically as it reaches the minimum height (fig.1.B). The float may be adjusted by shortening or lengthening the cable (fig.2). The pump will switch on if the water level is up to or above the maximum length of the float cable. To function correctly the float must move freely. Ensure the float can do so and that the cable is not restricted. Check that the pump and discharge are working correctly.



- 4.5. **USING AS A PUDDLE PUMP:** In order to draw water from a shallow depth, the float switch needs to be immobilized as in fig.3. In this mode the pump will not function automatically so, consequently, must be not be left unattended owing to the risk of overheating. The normal medium for cooling the pump motor is the water in which it is submerged, therefore excessive use in the open air carries the risk of damage.

5. MAINTENANCE

- ☐ **WARNING!** With the exceptions listed below, all pump, float and electrical cable service maintenance and repair must only be undertaken by an authorised service agent. Failure to observe this rule may be dangerous and will invalidate the warranty.
- ☐ **WARNING!** Ensure the pump is disconnected from the mains power supply before attempting any service or maintenance.
- 5.1. Keep all parts of the pump clean. Rinse, drain and allow to dry before storing the pump.

6. TROUBLESHOOTING

A) Motor operates but there is no suction.	<ol style="list-style-type: none"> 1. Water level below min suction depth. 2. Air bubbles in pump accumulated during submersion, or float is incorrectly positioned so that pump does not stop at minimum level and sucks in air. 3. Clogged intake or discharge pipe. 	<ol style="list-style-type: none"> 1. Stop the pump. 2. Release air by inclining the pump and re-immersing it in water. 3. Remove blockage, and clean the unit.
B) Reduced water volume for level of water.	<ol style="list-style-type: none"> 1. Discharge pipe too narrow. 	<ol style="list-style-type: none"> 1. Use wider diameter pipe.
C) The pump will not start or suddenly stops.	<ol style="list-style-type: none"> 1. No electrical power. 2. Float not working. 	<ol style="list-style-type: none"> 1. Check cable, plug and fuse. 2. Contact authorised service agent.



ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.



WEEE REGULATIONS

Dispose of this product at the end of its working life in compliance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE). When the product is no longer required, it must be disposed of in an environmentally protective way. Contact your local solid waste authority for recycling information.

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



01284 703534



sales@sealey.co.uk



www.sealey.co.uk