

- Hole punch sizes: 2.8, 3.0, 3.5, 3.8, 4.0, 5.0mmØ
- The eyelet, punch and die heads end each of the punches, screw into the head of the pliers.

For best results follow this procedure:

Punch a hole of the largest diameter through the material.



Push the eyelet through the hole.



When using the formers, the ready made side of the eyelet should sit in the former with the hole rather than the one with the raised cone. The raised cone forms the other side off the eyelet.

