

- 1/2/3/4/5/6: top shower head assembly
- 7:Upper pole
- 8: plug screw
- 9: fixing screw
- 10: Chrome fixing plate
- 11: T connector
- 12: Handset holder
- 13: Seals (fitted on connectors of upper pole)
- 14. Riser
- 15. Handshower(handset)
- 16. Shower hose
- 17. Washer
- 18. Divertor
- 19. Cranked connectors
- 20. Washer(In the cranked connector box)
- 21. Thermostatic bar valve
- 22/23. Bar valve outlet (fixed)
- 25.Washer
- 26. Shower hose

Installation Guide

- 1) Connect the upper pole 7 and riser 14 via T connector 11 Make sure handset holder 12 is fitted on straight riser 14
- 2) Mark out the position of the pole on the wall
- 3) Fit the cranked connectors 19 to the rear of the thermo valve and prepare the pipework.
- 4) Connect the bar valve

 Note: with the aid of cranked connectors 19, the inlet
 centres could vary
- 5) Fit the divertor 18 onto the top outlet of bar vavle
- 6) Attach the pole to the divertor
- 7) Connect top shower head, shower hose, handshower
- 8) Check for water leak

Check out our full range of Showers

Digital Showers
Mixer Showers
Power Showers
Smart Showers

Shower Towers

Electric Showers

From Top Shower Brands

Mira Showers

Aqualisa Showers

Triton Showers

Gainsborough Showers

Shower Pumps can upgrade your showering experience even more

Stuart Turner Shower Pumps

Salamander Shower Pumps

Grundfos Shower Pumps

