

- 1/2/3/4/5/6: top shower head assembly
- 7:Upper pole
- 8: plug screw
- 9: fixing screw
- 10: Chrome fixing plate
- 11: T connector
- 12: Handset holder
- 13: Seals (fitted on connectors of upper pole)
- 14. Riser
- 15. Handshower(handset)
- 16. Shower hose
- 17. Washer
- 18. Divertor
- 19. Cranked connectors
- 20. Washer(In the cranked connector box)
- 21. Thermostatic bar valve
- 22/23. Bar valve outlet (fixed)
- 25.Washer
- 26. Shower hose

## **Installation Guide**

- 1) Connect the upper pole 7 and riser 14 via T connector 11 Make sure handset holder 12 is fitted on straight riser 14
- 2) Mark out the position of the pole on the wall
- 3) Fit the cranked connectors 19 to the rear of the thermo valve and prepare the pipework.
- 4) Connect the bar valve
- Note: with the aid of cranked connectors 19, the inlet centres could vary
- 5) Fit the divertor 18 onto the top outlet of bar vavle
- 6) Attach the pole to the divertor
- 7) Connect top shower head, shower hose, handshower
- 8) Check for water leak

## **Check out our full range of Showers**

Digital Showers
Mixer Showers
Power Showers
Smart Showers

**Shower Towers** 

**Electric Showers** 

## **From Top Shower Brands**

Mira Showers

**Aqualisa Showers** 

**Triton Showers** 

**Gainsborough Showers** 

## Shower Pumps can upgrade your showering experience even more

**Stuart Turner Shower Pumps** 

Salamander Shower Pumps

**Grundfos Shower Pumps** 

