

# Sequential Mixer Tap Installation instructions



These instructions illustrate how to install BPLMON (Sequential basin mixer tap) to the BWBASIN/BASI1TH (450mm basin)

These instructions can be followed either prior or after installation of the basin to the wall.



1) Attach the two bolts to the bottom of the tap (short threaded end of bolts)



2) Push one of the FlexiTales through the desired tap-hole



3) Attach FlexiTale to the base of the tap and position the tap in place over the tap-hole



4) From the underside, attach second Flexitale to underside of tap



5) Position rubber washer over flexitales and bolts, followed by the metal washer. Use bolts to secure tap in place.

## **Check out our full range of Bathroom Suites**

Bathroom Suites By Range

Cloakroom Suites

Toilets

Bathroom Sinks / Wash Basins

Bidets

Baths

## **Wide variety of toilets**

Close Coupled Toilets

Wall Hung Toilets

Back To Wall Toilets

Furniture unit toilets

## **Huge Selection of Baths**

Acrylic Baths

Steel Baths

Shower baths

Freestanding baths

Small baths

Corner baths

Whirlpool baths

## **Don't forget the important bathroom suite extras**

Bath panels

Toilet seats

**plumbworld**  
**Big brands, small prices.**