



PETROL CULTIVATOR/ TILLER

32329

SPARE PARTS LISTING SHEET (ENGINE)

KEY NO.	PART NO.	STOCK NO.	DESCRIPTION	KEY NO.	PART NO.	STOCK NO.	DESCRIPTION
1	Y-MT254-58	36089	Screw M5 x 20	29-3	Y-MT254-86	36391	Filter cartridge
2	Y-MT254-59	36187	Starter assembly	29-4	Y-MT254-87	36465	Air filter bracket
3	Y-MT254-60	36188	Starter gasket	29-5	Y-MT254-88	36471	Air filter seat
4	Y-MT254-61	36224	Drive plate	30	Y-MT254-89	36514	Hex screws
5	Y-MT254-62	36235	Flat plate	31	Y-MT254-90	36534	Spring washer
6	Y-MT254-63	36239	Oil seal	32	Y-MT254-91	36549	Flat plate
7	Y-MT254-64	36251	Right engine case	33	Y-MT254-92	36551	Carburettor assembly
8	Y-MT254-65	36252	Pin	34	Y-MT254-93	36574	Carburettor gasket
9	Y-MT254-66	36254	Bearing	35	Y-MT254-94	36588	Intake pipe
10	Y-MT254-67	36265	Crankshaft assembly	36	Y-MT254-95	36598	Intake pipe gasket
11	Y-MT254-68	36267	Needle roller bearings	37	Y-MT254-96	36643	Cylinder
12	Y-MT254-69	36269	Piston pin	38	Y-MT254-97	36655	Spark plug
13	Y-MT254-70	36270	Woodruff key	39	Y-MT254-98	36657	Muffler gasket
14	Y-MT254-71	36273	Crankshaft paper pad	40	Y-MT254-99	36759	Muffler
15	Y-MT254-72	36274	Left engine case	41	Y-MT254-100	36761	Flat plate
16	Y-MT254-73	36288	Hex screw	42	Y-MT254-101	36817	Spring washer
17	Y-MT254-74	36289	Oil seal	43	Y-MT254-102	36835	Hex screw
18	Y-MT254-75	36291	Magnetic wheels	44	Y-MT254-103	36856	Muffler cover
19	Y-MT254-76	36292	Flange hex bolt M8	45	Y-MT254-104	36864	Hex screw
20	Y-MT254-77	36293	8 x 17 x 1.6 Flat plate	46	Y-MT254-105	36866	Top cover
21	Y-MT254-78	36294	Clutch assembly	47	Y-MT254-106	36869	Cylinder cover
22	Y-MT254-79	36332	Wave pad	48	Y-MT254-107	36870	Cylinder gasket
23	Y-MT254-80	36368	Bench screws	49	Y-MT254-108	36901	Piston ring
24	Y-MT254-81	36374	Fancover	50	Y-MT254-109	36945	Piston
25	Y-MT254-82	36383	Hex screws	51	Y-MT254-110	36948	Piston pin retaining ring
28	Y-MT254-83	36385	Hex screws	52	Y-MT254-111	36964	Fuel tank assembly
29-1	Y-MT254-84	36387	Air filter housing	53	Y-MT254-112	36973	Fuel tank damping plate
29-2	Y-MT254-85	36388	Air filter cover	54	Y-MT254-113	36977	Tank plate

Helpline: (023) 8049 4344. Sales Desk: (023) 8049 4333. General Enquiries: (023) 8026 6355.

DRAPER TOOLS LTD, HURSLEY ROAD, CHANDLER'S FORD, EASTLEIGH, HANTS. SO53 1YF. U.K website: drapertools.com e-mail: sales@drapertools.com



PETROL CULTIVATOR/ TILLER

32329

SPARE PARTS LISTING SHEET (FRAME ASSEMBLY)

KEY NO.	PART NO.	STOCK NO.	DESCRIPTION	KEY NO.	PART NO.	STOCK NO.	DESCRIPTION
1	Y-MT254-01	34781	Gearbox	29	Y-MT254-29	35456	Nut
2	Y-MT254-02	34803	Bearing	30	Y-MT254-30	35457	Aluminium tube
3	Y-MT254-03	34811	Worm drive	31	Y-MT254-31	35469	Drive shaft
4	Y-MT254-04	34863	Oil seal	32	Y-MT254-32	35489	Oil bearing
5	Y-MT254-05	34968	Worm cover pad	33	Y-MT254-33	35493	Sponge cover
6	Y-MT254-06	34980	Worm cover	34	Y-MT254-34	35580	Front bracket
7	Y-MT254-07	34998	Hex screw M5 x 16	35	Y-MT254-35	35606	Hex screw M6 x 25
8	Y-MT254-08	35079	Flange hex bolt	36	Y-MT254-36	35610	Round square neck bolt M6 x 35
9	Y-MT254-09	35091	Flat key	37	Y-MT254-37	35623	Hex screw M5 x 25
10	Y-MT254-10	35095	Cutter shaft	38	Y-MT254-38	35636	Holder under splint
11	Y-MT254-11	35122	Oil seal	39	Y-MT254-39	35638	Holder
12	Y-MT254-12	35129	Bearing	40	Y-MT254-40	35768	Holder on splint
13	Y-MT254-13	35131	Worm gear	41	Y-MT254-41	35950	Clutch housing
14	Y-MT254-14	35136	Worm gear cover pad	42	Y-MT254-42	35987	Hex screw M5 x 12
15	Y-MT254-15	35140	Worm gear cover	44	Y-MT254-44	35992	Rear bracket
16	Y-MT254-16	35219	Hex screw M6 x 20	45	Y-MT254-45	35999	Round square neck bolt M6 x 45
17	Y-MT254-17	35221	Hex screw M6 x 18	46	Y-MT254-46	36003	Star nut
18	Y-MT254-18	35238	Right blade	47	Y-MT254-47	36027	Hex screw M6 x 30
19	Y-MT254-19	35317	Left blade	48	Y-MT254-48	36029	Handle set
20	Y-MT254-20	35327	Pin	49	Y-MT254-49	36038	Throttle switch holder
21	Y-MT254-21	35330	Lock ring	50	Y-MT254-50	36048	Throttle switch
22	Y-MT254-22	35333	Front cover	51	Y-MT254-51	36052	Retainer pin
23	Y-MT254-23	35334	Wheel axle	52	Y-MT254-52	36063	Return spring
24	Y-MT254-24	35348	Flat pad	53	Y-MT254-53	36070	E-type retainer
25	Y-MT254-25	35365	Wheel	54	Y-MT254-54	36072	Ignition switch assembly
26	Y-MT254-26	35377	Split pin	55	Y-MT254-55	36076	Throttle cable assembly
27	Y-MT254-27	35387	Flat pad	56	Y-MT254-56	36078	Hex screw M5 x 35
28	Y-MT254-28	35397	Spring washer	57	Y-MT254-57	36086	Paper pad

Helpline: (023) 8049 4344. Sales Desk: (023) 8049 4333. General Enquiries: (023) 8026 6355.


DRAPER TOOLS LTD, HURSLEY ROAD, CHANDLER'S FORD, EASTLEIGH, HANTS. SO53 1YF. U.K website: drapertools.com e-mail: sales@drapertools.com



PETROL CULTIVATOR/ TILLER

32329

SPARE PARTS DRAWING SHEET (ENGINE)



Helpline: (023) 8049 4344. Sales Desk: (023) 8049 4333. General Enquiries: (023) 8026 6355.


DRAPER TOOLS LTD, HURSLEY ROAD, CHANDLER'S FORD, EASTLEIGH, HANTS. SO53 1YF. U.K website: drapertools.com e-mail: sales@drapertools.com



PETROL CULTIVATOR/ TILLER

32329

SPARE PARTS DRAWING SHEET (FRAME ASSEMBLY)



Helpline: (023) 8049 4344. **Sales Desk:** (023) 8049 4333. **General Enquiries:** (023) 8026 6355.

DRAPER TOOLS LTD, HURSLEY ROAD, CHANDLER'S FORD, EASTLEIGH, HANTS. SO53 1YF. U.K website: drapertools.com e-mail: sales@drapertools.com