


**DRAPER**<sup>®</sup>

20V BRUSHLESS

# NIBBLER

55742 - D20NS1700 SPARE PARTS DRAWING

**D20**  
MULTI-TOOL BATTERY SYSTEM



KEY No.	PART No.	STOCK No.	DESCRIPTION
4	YD20NS1700-4	98122	Allen key M5
5	YD20NS1700-5	98124	Circle blade holder assembly
6	YD20NS1700-6	98125	Circle blade
7	YD20NS1700-7	98121	Nut
8	YD20NS1700-8	98129	Self-tapping screw
9	YD20NS1700-9	98131	Head assembly
10	YD20NS1700-10	98134	Auxiliary handle
11	YD20NS1700-11	98135	Brushless motor

KEY No.	PART No.	STOCK No.	DESCRIPTION
13	YD20NS1700-13	98137	PCB & magnet ring
14	YD20NS1700-14	98138	Left shell
15	YD20NS1700-15	98203	Right shell
21	YD20NS1700-21	98205	Switch assembly
22	YD20NS1700-22		Battery pack
24	YD20NS1700-24	98206	Insert frame assembly
25	YD20NS1700-25	98132	Wrench
26	YD20NS1700-26	98128	Panhead self-tapping screw (set)