

THE TOOL COMPANY

# INTERCOM SYSTEM

■ STOCK No.63413

■ PART No.IC1

## • INSTRUCTIONS •

**IMPORTANT:** PLEASE READ THESE INSTRUCTIONS CAREFULLY TO ENSURE THE SAFE AND EFFECTIVE USE OF THIS ITEM/PRODUCT.



## GENERAL INFORMATION

This manual has been compiled by Draper Tools and should be kept with the product.

This manual describes the purpose for which this item/product has been designed and contains all the necessary information to ensure its correct and safe use. We recommend that this manual is read before any operation of the item/product, before performing any kind of adjustment to the item/product, and prior to any maintenance tasks. By following all the general safety instructions contained in this manual, it will ensure both item/product and operator safety, together with longer life of the item/product itself.

All photographs and drawings in this manual are supplied by Draper Tools to help illustrate the operation of the item/product.

Whilst every effort has been made to ensure accuracy of information contained in this manual, the Draper Tool policy of continuous improvement determines the right to make modifications without prior warning.



# DECLARATION OF CONFORMITY

We

Draper Tools Ltd. Hursley Road, Chandler's Ford, Eastleigh, Hampshire.  
SO53 1YF. England.

Declare under our sole responsibility that the product:

**Stock No:-** 63413.

**Part No:-** IC1.

**Description:-** Wired Video Intercom System.


To which this declaration relates is in conformity with the following directive(s)  
89/336/EEC.

With reference to: EN 55022:1994+A1:1995+A2:1997, EN 61000-3-2:1995+A13:1997, EN 61000-3-3:1995, EN 50082-1 (IEC 801-2):1992, EN 50082-1 (IEC 801-3):1992, EN 50082-1(801-4):1992.

A handwritten signature in black ink, appearing to read "John Draper".

JOHN DRAPER  
Managing Director



11/2000



## BATTERY INSTALLATION

The system is operated by one 9V (PP3) battery (not provided), Draper Stock Nos. 62044 or 61837 are recommended.




1. Dismount unit by releasing the securing screw under the unit.
  2. Push the unit from the bottom then pull it up from the top as shown in Fig.3.
  3. Remove the battery door on the back of the master unit.
  4. Connect the 9V battery to the snap connector.  
 Locate battery on sponge and replace the battery door (Fig.4).
- Replace the battery when the BAT. LOW Red L.E.D. is on.



# INSTALLATION

Choose the desired location, drill holes by placing the wall mounting bracket as a template. Using the fixings provided secure the bracket to the wall (Fig.7). Let the connection cable run through the hole in the mounting brackets and then plug into the units as shown in Fig. 5.

Adjust the speaker volume using a screwdriver on the back of the master unit (See Fig.4). Then clip the unit onto the bracket and secure it by fastening the securing screw at the bottom.



# OPERATION

## From Master Unit to Station

Press the 'CALL' button to send a call buzzer to the Station.

Press 'ON/OFF' button, the Green L.E.D. power indicator will come on.

Press the 'TALK' button for talking. For listening, release the button.

Switch off by pressing 'ON/OFF' button again when not in use.

## From Station to Master Unit

Press the 'CALL' button to send a call buzzer to the Master Unit.

When a reply is heard and 'IN USE' Red L.E.D. light is on, just talk and listen without pressing the button.

# OPTIONAL ACCESSORY

For prolonged continuous use, it is advisable to connect an A.C./D.C. mains adaptor (not provided) in place of a battery. To use mains adaptor (500mA 9-12V; Centre Positive Straight Female Type Plug Head, size see Fig.6) as power supply; plug adaptor's jack into the socket on the back of the master unit.

Stock No.64093      Part No.YIC1      A.C./D.C. Adaptor




<h1>NOTES</h1>
----------------



<h1>NOTES</h1>
----------------



<h1>NOTES</h1>
----------------



**DRAPER TOOLS LIMITED,**  
Hursley Road, Chandler's Ford, Eastleigh, Hants. SO53 1YF. U.K.  
Helpline: (023) 8049 4344.  
Sales Desk: (023) 8049 4333.  
General Enquiries: (023) 8026 6355.  
Fax: (023) 8026 0784.



[www.draper.co.uk](http://www.draper.co.uk)

e-mail: [sales@draper.co.uk](mailto:sales@draper.co.uk)

YOUR DRAPER STOCKIST

©Published by Draper Tools Ltd.  
No part of this publication may be reproduced,  
stored in a retrieval system or transmitted in  
any form or by any means, electronic, mechanical  
photocopying, recording or otherwise without prior  
permission in writing from Draper Tools Ltd.