



Item	Part No.	Description
1	EH5001.01	Cover, Grille
2	EH5001.02	Grille
3	EH5001.03	Heating Element
4	EH5001.04	Casing, Inner
5	EH5001.05	Time-Delay Thermostat
6	EH5001.06	Thermostat
7	EH15001.05	Clip, Sensor
8	EH9001.11	Wire Ring
9	EH5001.09	Casing, Outer
10	EH5001.10	Frame
11	EH5001.11	Handle Grip
12	EH5001.12	Control Box
13	EH9001.16	Power Switch, Rotary
14	EH5001.14	Knob, Mode Selection
15	EH15001.13	Ring, Mode Selection

Item	Part No.	Description
16	EH5001.16	Thermostat
17	EH5001.17	Cable Grip
18	EH9001.21	Relay
19	EH5001.19	Support, Relay
20	EH5001.20	Fan, Motor
21	EH5001.21	Support, Motor
22	EH5001.22	Motor
23	EH5001.23	End Plug
24	EH5001.24	Rubber Feet
25	EH9001.29	Adjusting Knob
26	EH9001.30	Rivet
27	EH5001.27	Mains Cable (c/w Plug)
28	EH5001.28	Connect Plate
29	EH5001.29	Support, Heating Element

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.