



Item	Part No.	Description
1	CB20V.01	Side Label (Right Side)
2	CB20V.02	Side Casing Screw (ST3.5x13)
3	CB20V.03	Right Outlet Cover Plate
4	CB20V.04	Self Tapping Screw 3.5x8
5	CB20V.05	Right Side Housing
6	CB20V.06	Switch
7	CB20V.07	Electrical Terminal
9	CB20V.09	Terminal Cover
10	CB20V.10	Terminal Lock
11	CB20V.11	Circuit Board
12	CB20V.12	Terminal Insert
13	CB20V.13	Circuit Board
14	CB20V.14	Self Tapping Screw (ST2.9x7)
15	CB20V.15	Connection Wire
16	CB20V.16	Capacitor
17	CB20V.17	Magnetic Ring Winding
18	CB20V.18	Square Magnetic Ring
19	CB20V.19	Magnetic Ring Winding

Item	Part No.	Description
20	CB20V.20	Motor
21	CB20V.21	Motor Protection
22	CB20V.22	Motor End Plate
23	MSP48.SB	Machine Screw Pan Head Phillips M4x8mm Black
24	CB20V.24	Fan
25	CB20V.25	Left Side Housing
26	CB20V.26	Side Label (Left Side)
27	CB20V.27	Air Flow Disc
28	CB20V.28	Left Outlet Cover Plate
29	CB20V.29	Middle Air Pipe
30	CB20V.30	Air Outlet Pipe
31	CB20V.31	Cross Head Screw ST4.2x8
33	CB20V.33	Guide Wheel
34	CB20V.34	Gasket
35	SN5.S	Steel Nut M5 Zinc
36	CB20V.36	Heat Tube 3x12
37	CB20V.37	Transparent Cover

**NOTE:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

**IMPORTANT:** No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

**WARRANTY:** Guarantee is 12 months from purchase date, proof of which will be required for any claim.