



Item	Part No.	Description
1	CP20VHG.01	Back Cover
2	CP20VHG.02	Housing Assembly
3	CP20VHG.03	Motor Assembly
4	CP20VHG.04	Heating Element Assembly
5	CP20VHG.05	Switch Sleeve
6	CP20VHG.06	Trigger Spring
7	CP20VHG.07	Trigger
8	CP20VHG.08	Safety Lock Assembly
9	CP20VHG.09	Switch
10	CP20VHG.10	PCB

Item	Part No.	Description
11	CP20VHG.11	LED Cover
12	CP20VHG.12	Screw for Inner Cover
13	CP20VHG.13	Inner Cover (Metal)
14	CP20VHG.14	Front Cover
15	CP20VHG.15	Battery Connector
16	CP20VHG.16	Screw for Housing
17	CP20VHG.17	Battery Terminal
20	CP20VHG.20	Reduction Nozzle
21	CP20VHG.21	Fish Tail Nozzle
22	CP20VHG.22	Deflector Nozzle

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.