


The Handy



Spreader
(THS80)
(Pre 2010)



Spreader (THS80) Pre (2010)

No	Part No	Description	Qty	No	Part No	Description	Qty
1	TH137-2	Bolt M6x25	1	25	TH137-24	Lock Nut M6	12
2	TH137-3	Lock Washer Ø8	1	26	TH138-26	Support Leg	1
3	TH138-3	Gauge Plate	1	27	TH138-27	Wheel Assembly Frame(Right)	1
4	TH137-5	Adjust Handle Pole	1	28	TH138-28	Thin Washer	1
5	TH137-6	Adjust Handle A	1	29	TH137-36	Pneumatic Wheel	2
6	TH137-7	Adjust Handle B	1	30	TH137-34	Flat Washer Ø16	1
7	TH137-8	Screw Ø4x18	1	31	TH137-35	End Cap	2
8	TH138-8	Handle Grip	1	32	TH137-37	Inner Axle Bushing	2
9	TH137-9	Spacer	1	33	TH137-38	Outer Axle Bushing	2
10	TH137-10	Wing Nut	1	34	TH137-39	Gear Box & Axle Assemble	1
11	TH138-11	Hopper	1	35	TH137-41	Screw M4x20	1
12	TH138-12	R Pin Ø2x60	1	36	TH137-47	Bolt M5x45	1
13	TH138-13	Center Cover	1	37	TH138-37	Line Clamp Press Plate	2
14	TH138-14	Bolt M6x65	4	38	TH138-38	Control Rod	1
15	TH137-27	Adjustable Plate	1	39	TH138-39	Screw M5x10	2
16	TH137-28	Big Flat Washer Ø4	3	40	TH137-12	Nylon Washer	1
17	TH137-29	Screw Ø4x12	3	41	TH137-13	Big Flat Washer Ø6	5
18	TH138-18	Wheel Assembly Frame(Left)	1	42	TH138-42	Handle	1
19	TH137-42	Impeller	1	43	TH138-43	Line Clamp	1
20	TH138-20	Bolt M6x35	3	44	TH138-44	Screw Ø5x15	1
21	TH137-44	Lock Nut M5	4	45	TH138-45	Big End Cap	1
22	TH138-22	Line Clamp Bottom Plate	1	46	TH138-46	Small End Cap	2
23	TH138-23	Tube End Cap	4	47	TH138-47	Fixing Connection Rod	1
24	TH138-24	Bolt M6x40	4	48	TH138-48	Screen	1
					TH138-49	Rain Cover	1