




# Petrol Mini Tiller (THPMT)






## Petrol Mini Tiller (THPMT)

No	Part No	Description	Qty	No	Part No	Description	Qty
1	TH127-1	See Engine Parts	1	19	TH127-19	SPONGE COVER	1
2	TH127-2	HANDLE	1	20	TH127-20	OUTER BLADE	2
3	TH127-3	HANDLE SET	2	21	TH127-21	INNER BLADE	2
4	TH127-4	SWITCH	1	22	TH127-22	WHEEL	2
5	TH127-5	THROTTLE TRIGGER	1	23	TH127-23	GEAR BOX ASSY	1
6	TH127-6	THROTTLE CABLE	1	30	TH127-30	WHEEL AXLE	1
7	TH127-7	SWITCH WIRE	1	38	TH127-38	PIN	4
8	TH127-8	STAR NUT	2	39	TH127-39	"R" CLIP	4
9	TH127-9	ROUND QUARE NECK BOLT M6X40	2	40	TH127-40	ROUND SQUARE NECK BOLT M6X25	2
10	TH127-10	BRACKET	1	41	TH127-41	E-TYPE CARD RING+FLAT PAD 10	2+4
11	TH127-11	CLUTCH HOUSING	1	42	TH127-42	M6 NUT DISH	2
12	TH127-12	HOLDERON THE SPLINT	1	43	TH127-43	HEXAGON BOLT M6 X 25 COMBINATION	5
13	TH127-13	HOLDER	1	44	TH127-44	FLAT PAD6+ELASTIC PAD 6	8+8
14	TH127-14	HOLDER UNDER THE SPLINT	1	45	TH127-45	HEXAGON BOLT M6 X 16 COMBINATION	5
15	TH127-15	SHAFT	1	46	TH127-46	NUT M6	8
16	TH127-16	OIL BEARING	2	47	TH127-47	ROUND SQUARE NECK BOLT M6 X 35	4
17	TH127-17	ALUMINUM	1	48	TH127-48	HEXAGON SCREW M5 X 25 COMBINATION	6
18	TH127-18	GUARD	1	50	TH127-50	HEXAGON SCREW M6 X 30 COMBINATION	4



## Petrol Mini Tiller (THPMT) Engine Parts





## Petrol Mini Tiller (THPMT) Engine Parts

<u>No</u>	<u>Part No</u>	<u>Description</u>	<u>Qty</u>	<u>No</u>	<u>Part No</u>	<u>Description</u>	<u>Qty</u>
1	TH127-1E	Bolt M5x16	1	36	TH127-36E	Bolt M5x20	1
2	TH127-2E	Air Filter Cover	1	39	TH127-39E	Engine Cowl	1
3	TH127-3E	Filter Cover	1	39A	TH127-39EA	Bolt M5x12	1
4	TH127-4E	Filter	1	43	TH127-43E	Spark Plug	1
5	TH127-5E	Bolt M5x55	1	45	TH127-45E	Muffler Gasket	1
6	TH127-6E	Air Filter Comb Assy	1	46	TH127-46E	Muffler	1
7	TH127-7E	Carburetor	1	47	TH127-47E	Washer	1
8	TH127-8E	Carburetor Gasket	1	48	TH127-48E	Bolts M6x55	1
9	TH127-9E	Boot Intake	1	49	TH127-49E	Muffler Cover	1
11	TH127-11E	Gasket Intake	1	50	TH127-50E	Washer	1
17	TH127-17E	Clutch Assy	1	57	TH127-57E	Rubber Gasket	1
21	TH127-21E	Coil	1	58	TH127-58E	Fuel Tank Connect Plate	1
33	TH127-33E	Housing - Starter Assy	1	59	TH127-59E	Fuel Tank	1
34	TH127-34E	Starter Gasket	1	60	TH127-60E	Bolt M5x20	1
35	TH127-35E	Starter Assy	1	61	TH127-61E	Fuel Tank Protector Plate	1