


8mm WET ROOM GLASS PANEL



BEFORE YOU START, HERE IS SOME IMPORTANT INFORMATION

1) General information

Please inspect this product upon delivery, any missing parts or manufacturing defects must be reported immediately to the supplier. Damage or defects reported later will not be accepted. TAKE CARE WHEN HANDLING GLASS PARTS - AVOID HEAVY CONTACT BETWEEN THE GLASS EDGES AND ANY HARD SURFACE. Glass breakage claims will not be accepted after the product has been unpacked.

Please note: Aluminium is a soft metal, and undergoes a series of extrusion, fabrication, polishing and anodising processes in order to create your finished shower enclosure. Some light surface marks are normal, and is result of the manufacturing processes. Quality control has ensured that this item is of a good standard, and is fit for purpose.

2) Additional Notes

Please read these instructions carefully before starting installation. Special care should be taken when drilling walls to avoid hidden pipes or electrical cables. Note: this product is heavy and may require two people to install.


TOOLS REQUIRED

DESCRIPTION	PART IMAGE
Tape measure	
Spirit level	
Pencil	
Ø6mm Drill bit	
Ø3mm Drill bit	

DESCRIPTION	PART IMAGE
Drill	T I Down
Cross head Screwdriver	(*)
Mallet	
Silicone Sealant	
Flat head Screwdriver	
Wrench	

ASSEMBLY INSTRUCTIONS - EXPLODED VIEW AND PARTS LIST

NB:ALL MEASUREMENT SIZES QUOTED ARE IN MM.



PACK I.D

E (1) 2x Screws 3.9x35

E (2) 1x bottom base

B (3) 1x Profile

PACK I.D

A (4) 1x Flipper panel


E (5) 1x Up base


C (6) 1x Glue strip

BOX CONTENTS


PACK I.D	Component	Picture
E	(1) 2x Screws 3.9x35	
E	(2) 1x bottom base	
В	(3) 1x Profile	
A	(4) 1x Flipper panel	
E	(5) 1x Up base	
С	(6) 1x Glue strip	


Step 1 - Atlach the bottom base to the profile and fix it with screws, Then fix the profile on another glass.





Step 2 - Install glue strip to the bottem of the glass Atlach the up base to the profile and fix it with screws.






Step 4 - SILICONING THE OUTSIDE EDGES.



Allow 24 hours for silicone to dry before use . Silicone on the outside edge only



CARE AND MAINTENANCE

1) AFTER CARE INSTRUCTIONS

Regularly clean your shower product with warm soapy water to prevent lime scale build up. Do not use abrasive cleaning fluids or materials, or strong chemical cleaners as this will damage the product surface.

2) MAINTENANCE

Clean the plastic parts with a cloth and mild detergent. Never use any abrasive creams, dissolvents, acetone or detergents and disinfectants that contain chlorine. The supplier accepts no liability for any type of use of care other than those contained in these instructions. The supplier reserves the right to introduce technical changes without notice.

COMMITMENT TO QUALITY

It is our intention that the quality and functions of this product are of the highest standard. If you require help we advise you firstly contact a competent plumber. However we understand that this may not always be the case, so should you experience any problems please contact our customer services quoting the following:

Product name: 8mm wetoom glass return panel

Product code: 7812

Customer help line number: 0344 804 48 48

INSTALLERS NOTES



Victoria Plum Limited, Bridgehead Business Park Hessle, HU130DG

> 17 EN 14428:2015 DOP No.:170928163GZU-001

Shower enclosures with aluminium profiles and safety glass

Essential characteristics	Performance	Harmonised technical specification
Cleanability	pass	Clause 4.2 of EN 14428:2015
Impact resistance/shatter properties	pass	Clause 4.3 of EN 14428:2015
Durability	pass	Clause 4.4 of EN 14428:2015

The packing you have received with your product is 100% recyclable.

It must be disposed of in a safe and environmentally friendly way.

We suggest you take it to the local landfill site and discard in the designated bins.