

1/2"SQ DRIVE TORQUE WRENCH MICROMETER STYLE 60-340NM -CALIBRATED

MODEL NO: STW704

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to instructions

1. SAFETY

- ✓ Ensure all workshop safety rules, regulations, and conditions are complied with when using torque wrench.
- Maintain the wrench in good condition and replace any damaged or worn parts. Use genuine parts only. Unauthorised parts may be dangerous and will invalidate the warranty.
- The wrench is a precision tool. **DO NOT** abuse it. **DO NOT** drop or throw the wrench.
- ✓ Maintain correct balance and footing. Ensure the floor is not slippery and wear non-slip shoes.
- WARNING! DO NOT use the wrench if damaged or thought to be faulty (contact Service Agent).
- DO NOT use wrench unless you have been instructed in its use by a qualified person.
- DO NOT use any cleaner which might affect the high pressure grease with which the wrench is packed.
- **DO NOT** apply more torque than the maximum scale reading.
- √ After use adjust to lowest torque setting (but not below), clean and store in a safe, dry, childproof location.

2. INTRODUCTION

Manufactured from hardened and tempered Chrome Vanadium steel with a polished satin finish. Smooth action ratchet head with flip reverse action to allow torquing in both directions. Easy to use torque adjustment, locks when required setting is selected. Calibration tolerance in accordance with BS EN ISO 6789-1:2017. Wrenches are individually tested to standards with ±4% accuracy and each wrench is issued with an individually numbered test certificate. Supplied in storage case.

3. SPECIFICATION

Model No:	STW704
Drive:	1/2"Sq
Length:	610mm
Range:	60-340Nm(44-250lb.ft)

4. OPERATION

- **4.1.** Hold torque wrench so that required scale on shaft, just above hand grip is uppermost and visible.
- **4.2.** Pull down the locking ring to unlock the hand grip.
- **4.3.** Turn hand grip to select torque setting as follows:

Required setting - 56Nm Hold back the locking ring and turn hand grip until top edge is level with the 55Nm line on the shaft scale and the 'zero' on the hand grip graduation is aligned with the centre line of the shaft scale.

Rotate the grip further, clockwise, until the '1' on the hand grip graduation is aligned with the centre line to give a setting of 55 + 1 = 56Nm.

- **4.4.** Release the locking ring to prevent accidental alteration of the setting.
- **4.5.** When tightening the nut/bolt you will feel and hear the wrench mechanism click when the set torque is reached. Immediately stop applying force to wrench to avoid over-tightening the nut/bolt.
- **4.6.** Wrench will reset ready for the next application.

NOTE: If wrench is not used for some while, operate it a few times, at a low setting, to ensure all internal parts are coated in grease.

5. RECALIBRATION

5.1. To ensure continued accuracy the wrench should be recalibrated annually and after any impact or other misuse. Contact an NAMAS accredited laboratory.

6. CALIBRATION CERTIFICATE

6.1. See last page for calibration certificate.



TORQUE TOOL CALIBRATION CERTIFICATE

Declaration of Conformance

(in accordance with BS EN ISO 6789-1:2017)¹

Test machine type/name	TORQUE TESTER
Test machine serial No.	4266
Test machine calibration date	2020/6/20
Measurement error	±1%

Measurement uncertainty	0.031kgf.m
Ambient temperature	30 °C
Humidity	59 %
Test units: (Nm, lb/ft etc)	Nm

<i></i>	1	Min Torque:	60	Cladavia					
	L	Max torque:	340	Clockwise					
Test	Test	Tolerance ± 4 % of Test Load			(Completed	test read	ing ³	
%	Load	Min	Max	1	2	3	4	5	Average
20%	68	65.28	70.72						
60%	204	195.84	212.16						
100%	340	326.40	353.60						

<i>-</i>	,	Min Torque:	60	Anti-clockwise					
4	Max torque: 340		(This part 2 to be completed only where applicab		olicable)				
Test	Test Test Tolerance ± 4 % of Test Load Completed test real			test readi	ing ³				
%	Load	Min	Max	1	2	3	4	5	Average
20%	68	65.28	70.72						
60%	204	195.84	212.16						
100%	340	326.40	353.60	·					

Tool Model Number	STW704
Tool Serial Number	
Tested by (print name)	John Li
Date of test ⁴	

Notes: ¹Testing is in compliance with International Standard procedures, with test equipment calibrated by a

∩ lack Saalay Limitad legge 10 20/05/18



ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Lifetime guarantee from purchase date, proof of which is required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR

1 01284 757500 01284 703534 sales@sealey.co.uk www.sealey.co.uk

 $^{^2}$ Measurement error shall be less than $\frac{1}{4}$ of the maximum permissible relative deviation of the torque tool.

³ The observed values fall within the maximum permissible deviation (tolerance). For tools with a flexible head, the result is valid only if the measuring axis is perpendicular to the axis of the tool.

⁴ This Sealey Declaration of Conformance is issued at the time of manufacture. Its' validity is open ended until the torque tool is used for the first time. The default re-calibration period of 12 months (or 5,000 cycles, whichever occurs first) starts after first use of the torque tool (BS EN ISO 6789-1:2017, clause 5.3 refers).