



# 20V 1/4"HEX DRIVE IMPACT DRIVER 180NM - BODY ONLY

MODEL NO: **CP20VID**

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

**IMPORTANT:** PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to instructions



Wear eye protection



Wear protective gloves



Wear ear protection

## 1. SAFETY

### 1.1. GENERAL SAFETY

- ✓ Maintain the Impact Driver and battery in good condition. Check moving parts alignment on a regular basis.
- ✓ Replace or repair damaged parts. Use an authorised service agent and recommended parts only. Unauthorised parts may be dangerous and will invalidate the warranty.
- ✓ Ensure the Impact Driver is switched off before installing the battery pack.
- ✓ Keep the Impact Driver and charger clean for best and safest performance.
- ✓ Remove ill fitting clothing. Remove ties, watches, rings and other loose jewellery and contain long hair.
- ✓ Evaluate your working area before using the Impact Driver; e.g. ceilings, floors and enclosures may contain electrical items or water piping.
- ✓ Ensure battery pack is correctly inserted into the Impact Driver handle and latched in place before attempting to switch on Impact Driver.
- ✓ Secure loose work pieces with a clamp, vice or other adequate holding device.
- ✓ Avoid unintentional starting.
- ✓ Wear approved safety eye protection (standard spectacles are not adequate).
- ✓ Maintain correct balance and footing. Ensure the floor is not slippery and wear non-skid shoes.
- ✓ Keep direction switch in the locked position until the Impact Driver is required for use.
- ✓ Keep children and unauthorised persons away from the working area.
- \* **DO NOT** use the Impact Driver where there are flammable liquids, solids or gases, such as paint solvents, etc.
- \* **DO NOT** allow children to operate the Impact Driver.
- \* **DO NOT** operate the Impact Driver if any parts are missing as this may cause failure and/or personal injury.
- \* **DO NOT** hold unsecured work piece in your hand.
- \* **DO NOT** leave the Impact Driver operating unattended.
- \* **DO NOT** carry the Impact Driver with your finger on the power switch. Keep chuck direction switch in the locked position.
- \* **DO NOT** use the Impact Driver for a task it is not designed to perform.
- \* **DO NOT** operate the Impact Driver when you are tired or under the influence of alcohol, drugs or intoxicating medication.
- \* **DO NOT** get the Impact Driver or battery charger wet or use in damp or wet locations.

## 2. INTRODUCTION

Powerful, lightweight cordless impact driver. Durable composite housing with soft grip for added comfort. 1/4"Hex quick release chuck. Variable speed control trigger. Forward, reverse and trigger-lock. Built-in LED work light. Supplied with belt hook for safer storage whilst not in use. Requires compatible 20V battery and mains charger, sold separately.

## 3. SPECIFICATION

Model No..... CP20VID  
 Battery .....20V 2Ah - 6Ah Lithium-ion (not included)  
 Consumable parts:  
 CP20VBP2 - 2Ah Battery, CP20VBP4 - 4Ah Battery, CP20VBP6 - 6Ah Battery  
 Drive ..... 1/4" hex  
 Impact rate ..... 0-3000bpm  
 Max. torque ..... 180Nm  
 Noise power/pressure ..... 106/95dB(A)  
 No-load speed.....0-2200rpm  
 Replacement parts  
 ..... CP20VMC - Mains Charger (not included)  
 Vibration/uncertainty ..... 15.87/1.5m/s<sup>2</sup>

## 4. OPERATION

- 4.1. Ensure the direction selector (fig.1) is in the mid (lock) position.
- 4.2. Insert the required driver bit into the chuck by pulling the locking collar forward and sliding the bit in until the locking ring snaps back.
- 4.3. Select clockwise or anticlockwise direction by means of the direction selector.
- 4.4. Squeeze the trigger to start the driver; initial pressure switches on the LED worklight, further pressure starts the motor and increases speed.
- 4.5. To release the bit, pull the locking collar forward and withdraw.



### **WARNING! – Risk of Hand Arm Vibration Injury.**

This tool may cause Hand Arm Vibration Syndrome if its use is not managed adequately. This tool is subject to the vibration testing section of the Machinery Directive 2006/42/EC. This tool is to be operated in accordance with these instructions.

Measured vibration emission value (a): . . . . . 15.87 m/s<sup>2</sup>

Uncertainty value (k): . . . . . 1.5 m/s<sup>2</sup>

Please note that the application of the tool to a sole specialist task may produce a different average vibration emission. We recommend that a specific evaluation of the vibration emission is conducted prior to commencing with a specialist task.

A health and safety assessment by the user (or employer) will need to be carried out to determine the suitable duration of use for each tool.

NB: Stated Vibration Emission values are type-test values and are intended to be typical.

Whilst in use, the actual value will vary considerably from and depend on many factors.

Such factors include; the operator, the task and the inserted tool or consumable.

NB: ensure that the length of leader hoses is sufficient to allow unrestricted use, as this also helps to reduce vibration.

The state of maintenance of the tool itself is also an important factor, a poorly maintained tool will also increase the risk of Hand Arm Vibration Syndrome.

Health surveillance.

We recommend a programme of health surveillance to detect early symptoms of vibration injury so that management procedures can be modified accordingly.

Personal protective equipment.

We are not aware of any personal protective equipment (PPE) that provides protection against vibration injury that may result from the uncontrolled use of this tool. We recommend a sufficient supply of clothing (including gloves) to enable the operator to remain warm and dry and maintain good blood circulation in fingers etc. Please note that the most effective protection is prevention, please refer to the Correct Use and Maintenance section in these instructions. Guidance relating to the management of hand arm vibration can be found on the HSC website [www.hse.gov.uk](http://www.hse.gov.uk) - Hand-Arm Vibration at Work.



### **ENVIRONMENT PROTECTION**

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.



### **WEEE REGULATIONS**

Dispose of this product at the end of its working life in compliance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE). When the product is no longer required, it must be disposed of in an environmentally protective way. Contact your local solid waste authority for recycling information.

**Note:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

**Important:** No Liability is accepted for incorrect use of this product.

**Warranty:** Guarantee is 12 months from purchase date, proof of which is required for any claim.

**Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR**



**01284 757500**



**01284 703534**



**sales@sealey.co.uk**



**www.sealey.co.uk**